# **LED remote:** a fully networked control centre that's fun to use.

**BOSCH**
Invented for life

# **LED remote** at a glance

⏻ Switching on/off

**A** Charge level LEDs: Display of the current battery charge level

**B** Riding mode LED: The colour shows the current support level

**C** Left/right button: Decrease/increase brightness

**D** Selection key: Confirm/Switch to 2nd level

**E** Plus/Light button: Increase support level/switch light on & off (long press)

**F** Minus/walk assistance button: Reduce support level/activate walk assistance by holding down & moving the eBike after one second

**Use the + and − keys to select one of the assisted riding modes\***

| | |
|---|---|
| **Eco** | Effective support for maximum range |
| **Tour** | Consistent support for long rides |
| **Tour+** | Continuous support and energy-saving riding |
| **Sport** | Powerful support for universal uses |
| **eMTB** | Progressive support for a natural riding sensation |
| **Turbo** | Maximum support for a sporty ride |

**The eBike Flow app: Enhance your riding experience with the smart system**



The eBike Flow app gives users of compatible smartphones access to numerous features, integrates personal favourite apps such as Apple Health, and automatically synchronises activity data. Simply connect the smartphone to the eBike via the LED remote using Bluetooth.