

bosch-ebike.com

# System Controller and Mini Remote – smart addition for intuitive operation



Download the eBike  
Flow app (for Android  
7.1 or iOS 14 onwards)



**BOSCH**  
Invented for life

# System Controller and Mini Remote

at a glance

The smart  
system



## System Controller:

The minimalist and compact control unit for eBikes with the smart system houses the essential features only. The scope of functions and information is deliberately limited – so you have a quick overview that won't distract you when riding. The System Controller is seamlessly integrated into the top tube and, together with the Mini Remote, gives you extra functions.

- A** Displays the support levels
- B** Switch the eBike system on/off
- C** Increase the support level,<sup>1</sup> reduce the support level,<sup>2</sup> acknowledge errors
- D** ABS function display (if available) and ambient light sensor
- E** Battery charge level

## Mini Remote:

The optional and ideal addition to the System Controller providing extra functions that can be operated safely. Connected to the System Controller via Bluetooth, you can fit it wherever you like on the handlebar. The dual-function buttons on the Mini Remote allow you to change the riding mode, switch the light on/off, activate smart walk assist and control a display.

- F** Increase the support level, switch the light on<sup>2</sup>
- G** Reduce the support level, activate walk assist with hill hold (keep the minus button held down and move your eBike)
- H** Wireless installation on the handlebar
- I** Selection key to confirm, to scroll through the screens and to open options<sup>2</sup> in connection with a display

<sup>1</sup> Short press (< 1 second)

<sup>2</sup> Long press (> 1 second)