



### LCD COMPACT EX

Control and Information in a Compact

- ☾ Light On/Off
- ⚠ Alert / Reminder
- 📶 App Connected

#### SYSTEM STATUS

+ UP

- DOWN

🔌 ON/OFF

ON: Long Press  
OFF: Long Press



#### MAIN INFORMATION

Short press 🔌 ON/OFF to switch between Speed/Range display.

#### BATTERY LEVEL

- 🔋 81% - 100%
- 🔋 61% - 80%
- 🔋 41% - 60%
- 🔋 21% - 40%
- 🔋 1% - 20%


🚶 WALK

Press + UP / - DOWN to switch levels.

- 📖 SPORT
- 📖 TOUR
- 📖 ECO
- 📖 OFF

- ☾ LIGHT ON/OFF: Long Press + UP.
- 🚶 WALK ASSIST: Long Press 🚶 WALK to Unlock, then Hold + UP to start.
- 🚲 APP CONNECT: Double Click 🔌 ON/OFF.

### SMARTLY CONNECT YOUR E-BIKE



Download **Hyena Rider Assistant**. Elevate your ride with a dynamic dashboard, riding data analysis, smart e-bike management, OTA updates, and personalized settings, for an unparalleled riding experience.



Android



iOS